

Duct Inspection from Construction to Leakage Testing

Presenter: Mark Terzigni

Tuesday, September 12, 2017

8:00 AM - 11:15 AM









Information Required for Duct Construction

- A comprehensive duct layout indicating sizes, design airflows, pressure class, and routing of the duct system.
- The types of fittings to be used based on the designer's calculations of fitting losses (i.e., square versus 45° entry taps, conical versus straight taps, etc.).



Information Required for Duct Construction

- 3. Use of turning vanes or splitter vanes.
- 4. Location of access doors.
- Location and type of control and balancing dampers.
- 6. Location and types of diffusers.
- 7. Requirements for duct insulation.




Information Required for Duct Construction


8. Location and types of any fire protection device including fire dampers, smoke dampers, combination fire/smoke dampers, and ceiling dampers. Building codes require this information to be shown on the design documents submitted for building permit.





Information Required for Duct Construction


 Details of offsets required to route ductwork around obstructions (columns, beams, etc.).



















2017 ICC Annual Conference Education Programs Columbus, OH

























2017 ICC Annual Conference Education Programs Columbus, OH

















Basic Duct Construction Process


- Verify pressure class
- Check corresponding table
- Start with the larger side first
- Determine reinforcement spacing options
- Check joint reinforcement tables
- Check intermediate reinforcement tables if applicable (tie rod options next webinar)
- Repeat for the short side








In Words...


- If the box in the table shows H-20G
- The minimum panel gage is 20
- The reinforcement required is class H at the spacing noted at the top of the column (this can be a joint or intermediate reinforcement)
- You can use G instead of H if you use a tie rod as well. (If to achieve a class G you are already required to use a tie rod then you can not use this option)






























	Exampl	e 1						(1)	MACNA
½ in. wg Static Pos. or Neg.	No Reinforcement	Reinforcement Code for Duct Gage Number Reinforcement Spacing Options							
Duct Dimension	Required								
		10 ft	8 ft	6 ft	5 ft	4 ft	3 ft	2½ ft	2 ft
1)	2	3	4	3	6	1	(8)	9	(10)
10 in. and under	26 ga.								
11 - 12 in.	26 ga.	Not Required							
13 – 14 in.	26 ga.								
15 – 16 in.	26 ga.								
17 – 18 in.	26 ga.	L							
19 – 20 in.	24 ga.	B-26	B-26	B-26	B-26	B-26	B-26	A-26	A-26
21 – 22 in.	22 ga.	B-26	B-26	B-26	B-26	B-26	B-26	B-26	A-26
Page 2.14									





Example 1 Solutions Option 1 Use 24 gage No reinforcement required either side Option 2 Use 26 gage T-1 (plain drive) on the 20 in. side at a max spacing of 10 ft No reinforcement required on the 12 in. side






























2017 ICC Annual Conference Education Programs Columbus, OH





2017 ICC Annual Conference Education Programs Columbus, OH








Example 2 Solution


- Duct gage is 20
- Joint spacing is 5 feet (56 ¼ in.)
- TDC/TDF for transverse joint
- o Intermediate reinforcement (2 ½ feet)
 - G class
 - OAngle 1 1/2 x 1 1/2 x 1/8
 - ONot required on the 26 in. side





Intermediate External Reinforcement

- Reinforcement Intervals do not need to coincide
- At 4 in. positive pressure and above reinforcements must be tied
- Must be fastened to the duct within 2 in. from the corner (unless tied)
- Maximum fastener spacing is 12 in.











2017 ICC Annual Conference Education Programs Columbus, OH





2017 ICC Annual Conference Education Programs Columbus, OH

