

# 2012 International Existing Building Code Errata

(Portions of text and tables not shown are unaffected by the errata)

5<sup>th</sup> PRINTINGS (January 22, 2020)

## CHAPTER 14 PERFORMANCE COMPLIANCE METHODS

**TABLE 1401.6.11**  
**MEANS OF EGRESS VALUES<sup>a</sup>**

OCCUPANCY	CATEGORIES				
	a <sup>a</sup>	b	c	d	e
A-1, A-2, A-3, A-4, E, I-2	-10	0	2	8	10
M	-3	0	1	2	4
B, F, S	-1	0	0	0	0
R	-3	0	0	0	0

a. The values indicated are for buildings six stories or less in height. For buildings over six stories above grade plane, add an additional -10 points.

# 2012 International Existing Building Code Errata

(Portions of text and tables not shown are unaffected by the errata)

1<sup>st</sup> and 2<sup>nd</sup> PRINTINGS (October 31, 2012)

## CHAPTER 14 PERFORMANCE COMPLIANCE METHODS

### [B] TABLE 1401.6.19 INCIDENTAL USE AREA VALUES<sup>a</sup>

PROTECTION REQUIRED BY TABLE <del>508.2.5-509</del> OF THE INTERNATIONAL BUILDING CODE	PROTECTION PROVIDED						
	None	1 hour	AS	AS with SP	1 hour and AS	2 hours	2 hours and AS

**a.** AS = Automatic sprinkler system;  
SP = Smoke partitions (See IBC Section ~~508.2.5-509.4~~).

**Note:** For Table 1401.7, see page 68.

### [B] TABLE 1401.7 SUMMARY SHEET- BUILDING CODE

SAFETY PARAMETERS	FIRE SAFETY (FS)	MEANS OF EGRESS (ME)	GENERAL SAFETY (GS)
1401.6.13 Maximum Exit Access Travel Distance	****		
1401.6.14 Elevator Control	****		
1401.6.15 Means of Egress Emergency Lighting			
1401.6.16 Mixed Occupancies		**** ÷2 =	
1401.6.17 Automatic Sprinklers			
1401.6.18 Standpipes			
1401.6.19 Incidental Use		÷2 =	

\*\*\*\* No applicable value to be inserted.